

 LIONCAST

Battery Charger

+ 2100mAh Batteries



For / für Xbox Series X/S and
Xbox One X/S



Battery Charger

+ 2100mAh Batteries

Health and safety information

Please read and observe the following health and safety information carefully before using the device. Failure to do so may result in damage or injury. Use of the product by children only under adult supervision.

Warning

Notes on electrical safety

If possible, keep the battery charge level below 25%. Fully charged batteries can catch fire or explode if damaged.

Do not store, use, or charge the battery in extremely hot or cold temperatures. Keep the battery out of direct sunlight.

Always keep the battery away from easily flammable materials. Always keep the battery away from moist environments, and never immerse it in water. Loose batteries must be kept in non-conductive containers.

Never use batteries which are visibly leaking or whose casings, insulation, or terminals are physically damaged.

Batteries should be disposed of and recycled according to your local laws.

Functional illustration



LED display shows charging status in real time

Charging contacts

Functions

- Simultaneously charges up to two 2100mAh batteries for Xbox Series X/S and Xbox One X/S controllers.
- Two individual charge indicators show the charge status for each battery



Red LED Display: Controllers are charging (progress is shown by the bars).

Progress is shown by the bars. The more bars visible, the more charged the battery is).



Green LED Display: Controllers are fully charged




No LED-Display: No charging process

- Easy attachment and removal of the batteries thanks to custom-fit charging holders.
- Thanks to the exchangeable micro-USB cable, the length to the power source can be individually selected! Note: Depending on the length and type of cable, the charging time of the batteries may be longer. We recommend that you always use the cable supplied.
- Three power sources are available: Xbox Series X/S, Xbox One X/S, USB-AC Adapter and USB Power Bank. Note: The power of the power source affects the charging time. If the power source is too weak, the charging process will take longer than indicated!
- Integrated safety mechanisms: Overcurrent protection,
- short-circuit protection, overvoltage and low-voltage protection.

Features

- 2 x 2100mAh batteries included
- Compatible with XBox Series S and X as well as XBox One S and X
- 80cm USB-C to USB-A charging cable
- Weight (total): 180g
- Dimensions: 94x71x30mm
- Input: 5V/2A / Output: 5V/1A


How to place and charge the batteries!



Step 1:

Place batteries in the slots according to the polarity position (+/-) indicated on each slot.

WARNING: if an AAA battery is inserted from the (+) end first, the (-) terminal on the charger might be damaged.




Step II:

Charge either one or two batteries simultaneously.

Step III:


Plug the charger into a standard 100-240V AC outlet.





Step IV:

Check the LED light on the unit.
Steady green light = Fully Charged



Step V:

Open the battery compartment of your controller.

Insert the battery pack with the connection side first, aligned with the connection points in the compartment.

The battery is designed to be inserted only in this direction.

Declaration of Conformity

Stage10 GmbH hereby declares that the product is in conformity with the relevant Union harmonization legislation(s) (2014/53/EU et al).

The full text of the EU declaration of conformity is available at the following Internet address:

<https://support.lioncast.com/hc/de/articles/360016208020>

Manufacturer Information and Service

If you have questions regarding the product or if any problems occur during operation or similar, first contact the following body via e-mail:

info@lioncast.com

Lioncast is a trademark of Stage10 GmbH |
Torstr. 49 | 10119 Berlin | Germany

Disposal

Disposing of the packaging



Dispose of the packaging sorted into single-type materials:

- Paperboard and cardboard for recycled paper
- Films in the recyclable material collection service

Disposing of the device

(Applicable in the European Union and other European states with systems for the separate collection of reusable waste materials)



If the product is no longer operational, every consumer is **required by law to dispose of used devices separately from household waste**, e.g. at a collection point run by the communal authority/borough. This ensures that old devices are recycled in a professional manner and also rules out negative consequences for the environment. For this reason, electrical equipment is marked with the symbol shown here.

 **LIONCAST**

Lioncast Battery Charger +Batteries
for/für XBox Series S and X

Item no: I6064

EAN: 4 250541 924952

Lioncast[®] is a registered trademark of
Stage10 GmbH

Torstr. 49

10119 Berlin

Germany

Made in China

Microsoft[®], XBOX[®], XBOX Series[®] &
XBOX One[®] are registered trademarks of
Microsoft Corporation.

