



Wireless Microphone Set

For Video Game Consoles and PC

Content:

- » 2x Lioncast Wireless Microphone
- » 1x USB-A Dongle
- » Manual

System requirements:

Compatible with commercially available PCs and notebooks with a free USB 2.0 port

- » Win10, Win11
- » A device with USB-A port

Compatible with the following consoles:

- » PS4 / PS5
- » Switch / Switch OLED / Switch 2

Features:

- » Compatible with a wide range of consoles
- » Plug'n Play principle
- » Ergonomic design
- » Fits comfortably in the hand and is designed for long gaming sessions
- » 2.4GHz transmission for an undisturbed gaming experience
- » Integrated stand-by mode
- » Conveniently powered by 2 AA or rechargeable batteries (sold separately)
- » Long-lasting gaming fun

Technical Details:

MICROPHONE DIMENSION:	242mm x 52mm (length x diameter)
DIMENSION DONGLE:	50mm x 19mm x 9mm (length x width x height)
WEIGHT MICROPHONE:	103g (without batteries)
WEIGHT DONGLE:	5g
BATTERY:	2x AA (not included)
WORKING RANGE:	<10m
VOLTAGE MICROPHONE:	5V
VOLTAGE DONGLE:	5V USB port
SENSITIVITY:	-64+-2dB
FREQUENCY:	60-14kHz

LED status notifications:

Microphone LED:

- » After switching on the microphone, the LED flashes blue.
- » If the microphone is connected to the 2.4GHz dongle, the LED lights up blue quickly
- » The LED is red when the microphone is muted.
- » If the battery is running low, the status LED flashes red/blue (violet).

2.4GHz Dongle:


- » After plugging the 2.4GHz dongle into a USB-A port, the LED flashes blue quickly.
- » When the 2.4GHz dongle is connected to the microphone, the LED lights up blue.
- » The LED switches off if no connection to the microphone can be established within 10 minutes.

Power Button:

- » To switch on the microphone, press and hold the power button for 2 seconds.
- » To switch off the microphone, press and hold the power button again for 2 seconds.
- » To mute the microphone, press the power button once and press again to unmute the microphone

Note: If the microphone and dongle are not connected, hold the microphone close to the dongle.

**Reset here with
needle**



How to use:


1. Please remove the battery cover by twisting off the cover.
2. Insert the batteries properly
3. Press and hold the power button on the microphone for 3 seconds. The LED will now flash blue steadily.
4. Plug the 2.4GHz dongle into a USB-A port.
5. The microphone and 2.4GHz dongle will now connect and the LED will turn solid blue.
6. The microphone switches off when not in use for 10 minutes and can be switched on by pressing the power button again for 3 seconds.

Use with Consoles:

1. Plug the 2.4GHz dongle into a USB-A port.
2. Press and hold the power button on the microphone for 3 seconds. The LED will now flash blue steadily.
3. Switch on the console.
4. The microphone and the 2.4GHz dongle will now connect and the LED will turn solid blue.
5. Use the controller of the console to start the game.
6. The microphone is now usable

For Switch / Switch 2 additionally:

7. Go to Settings
8. Select Audio
9. Select Microphone Input
10. Change from Automatic to USB (USB Microphone)



Declaration of Conformity

Stage10 GmbH hereby declares that the product is in conformity with the relevant Union harmonization legislation(s) (2014/53/EU et al). The full text of the EU declaration of conformity is available at the following Internet address:



<https://support.lioncast.com/hc/de/categories/29824270813586-Konformit%C3%A4t>

Manufacturer Information and Service

If you have questions regarding the product or if any problems occur during operation or similar, first contact the following body via e-mail:

info@lioncast.com

Lioncast is a trademark of Stage10 GmbH |
Oranienburger Str. 45 | 10117 Berlin | Germany

Disposal

Disposing of the packaging



Dispose of the packaging sorted into single-type materials:

- Paperboard and cardboard for recycled paper
- Films in the recyclable material collection service

Disposing of the device

(Applicable in the European Union and other European states with systems for the separate collection of reusable waste materials)



If the product is no longer operational, every consumer is **required by law to dispose of used devices separately from household waste**, e.g. at a collection point run by the communal authority/borough. This ensures that old devices are recycled in a professional manner and also rules out negative consequences for the environment. For this reason, electrical equipment is marked with the symbol shown here.







Lioncast Wireless Microphone Set

For video game consoles and pc

Item no: 16105



4 250541 928974

Lioncast® is a registered trademark of **Stage 10 GmbH**

Oranienburger Str. 45

10117 Berlin

Germany

Made in China

